

# DOMINAR 400

OWNER'S MANUAL



To keep your bike in perfect running condition, please follow the periodic maintenance services which includes **3 Free and subsequent Paid services**, as per the schedule contained in this booklet.

अपनी बाइक को सही चलती हालत में रखने के लिए, कृपया आवधिक रखरखाव सेवाओं का पालन करें जिसमें ३ निःशुल्क और बाद में भुगतान सेवाएं शामिल हैं, इस पुस्तिका में दिए गए अनुसूची के प्रति।

आपली बाईक परिपूर्ण स्थितीत चालू ठेवण्यासाठी कृपया या बुकलेटमध्ये दिलेल्या शेड्यूलनुसार पीरिऑडिक मेन्टेनन्स सर्व्हिसेचे अनुकरण करा. यात 3 फ्री आणि त्यानंतरच्या पेड सर्व्हिसेस समाविष्ट आहेत.

ನಿಮ್ಮ ಬೈರ್ ಸಂಪೂರ್ಣ ಚಾಲನಾ ಸ್ಥಿತಿಯಲ್ಲಿರಲು, ದಯವಿಟ್ಟು ಈ ಕೈಪಿಡಿಯಲ್ಲಿ ನಮೂದಿಸಲಾದ ಶೆಡ್ಯೂಲ್ ನಂತರ ನಿಯತಕಾಲಿಕ ನಿರ್ವಹಣಾ ಸೇವೆಗಳನ್ನು ಅನುಸರಿಸಿ. ಇದು 3 ಉಚಿತ ಮತ್ತು ನಂತರ ಪಾವತಿ ಸೇವೆಗಳನ್ನು ಒಳಗೊಂಡಿರುತ್ತದೆ.

உங்களுடைய ஐக்கை மிக நன்றாக ஓடும் நிலையில் வைத்திருப்பதற்கு, இந்தக் கையேட்டில் கொடுக்கப்பட்ட அட்டவணையில் உள்ளவாறு 3, லவச மற்றும் தொடர்ச்சியான கட்டண சேவைகளை உள்ளடக்கிய காலமுறை பராமரிப்பு சேவைகளை தயவு செய்து பின்பற்றவும்.

మీ బైక చక్కటి రన్నింగ్ కండిషన్ లో ఉండాలంటే బుక్ లెట్ట్ ఉన్న పెడ్యూల్ ప్రకారం క్రమం తప్పకుండా మెయింటెనెన్స్ సర్వీసు చేయించండి. ఇందులో 3 ఉచిత సర్వీసులు, ఆ తర్వాత పెయిడ్ సర్వీసులు ఉన్నాయి.

നിങ്ങളുടെ ബൈക്ക് തികഞ്ഞ റണ്ണിംഗ്  
 കണ്ടീഷനില് സന്ദക്ഷിക്കാന് 3 സൗജന്യവും തുടര്ന്ന് പണം  
 നല്കിയിട്ടുള്ളതായാ മെയ്നറേന്സ് സരീസുകളിലേയ്ക്കായി  
 സൗജന്യമായ ഈ ബുക്കിംഗിലെ ക്രമപട്ടികയില്  
 കാണിച്ചപ്രകാരം പാലിക്കുക.

আপনার বাইক নির্ভুলভাবে চালু অবস্থায় রাখার জন্য, নির্দিষ্ট সময় অন্তর রক্ষণাবেক্ষণ পরিষেবা অনুসরণ করুন যার মধ্যে আছে ৩টি বিনামূল্যে এবং পরবর্তী মূল্যভিত্তিক পরিষেবা, এই পুস্তিকার অন্তর্ভুক্ত তালিকা অনুযায়ী।

ଆପଣଙ୍କର ବାକକୁ ଉପଯୁକ୍ତ ରିଟିଂ ଅବସ୍ଥାରେ ରଖିବା ପାଇଁ ପିରିଓଡିକ୍ ମୋନିଟରିଂ ସର୍ଭିସ୍ ଆନୁସରଣ କରନ୍ତୁ ଯେଉଁଥିରେ ଅନ୍ତର୍ଭୁକ୍ତ ରହିଛି 3 ଟି ମାଗଣା ଓ ପରବର୍ତ୍ତୀ ପେର୍ ସର୍ଭିସ୍ ଯାହାର ସିଡ୍‌ଲାଇନ୍ ଏହି ବୁକ୍‌ଲେଟରେ ପ୍ରଦାନ କରାଯାଇଛି ।

તમારી બાઇકને સંપૂર્ણ ચાલુ સ્થિતિમાં રાખવા માટે, કૃપા કરી નીચે મુજબ સમયાંતરની જાળવણી સર્વિસનું પાલન કરો જેમાં ૩ મફત અને પછી ચૂકવણી સર્વિસનો સમાવેશ થાય છે, આ પુસ્તિકામાં સમાવિષ્ટ સમયક્રમ મુજબ

ਆਪਣੀ ਬਾਣੀਕ ਨੂੰ ਚਲਦੀ ਹਾਲਤ ਵਿੱਚ ਰਖਣ ਲਈ, ਕਿਰਪਾ ਆਵਰਤੀ-ਸੰਭਾਲ ਸੇਵਾ ਦਾ ਪਾਲਨ ਕਰੋ ਜਿਸ ਵਿੱਚ 3 ਮੁਫਤ ਅਤੇ ਬਾਦ ਵਿੱਚ ਭੁਗਰਾਨ ਸੇਵਾਵਾਂ ਸ਼ਾਮਲ ਹਨ, ਇਸ ਕਿਤਾਬ ਵਿੱਚ ਦਿੱਤੇ ਗਏ ਅਨੁਸੂਚੀ ਦੇ ਪ੍ਰਤਿ।

আপোনার বাইকখন সঠিকভাৱে চলি থকা স্থিতিত ৰাখিবলৈ, অনুগ্ৰহ কৰি নিয়মীয়া তত্ত্বাবধান সেৱা অনুসৰণ কৰিব য'ত অন্তৰ্ভুক্ত থাকে 3 টা বিনামূলীয়া আৰু তাৰ পিছৰ পৰিশোধ কৰা সেৱা, এই পুস্তিকাখনত অন্তৰ্ভুক্ত অনুসূচী অনুসৰি।

اپنی بائیک کو بہترین رنگ حالت میں رکھنے کے لیے، براۓ مہربانی وقت وقت سے میٹیننس کی خدمات پر عمل کریں جس میں شامل ہیں: اس کتابچہ میں دئے گئے وقت کے مطابق 3 مفت سروسز اور بعد کی ہیڈ سروسز۔



## WELCOME TO THE DOMINAR CLAN!

You are now the proud owner of the modern masterpiece, Dominar 400. The new Dominar 400 is designed to deliver unparalleled technology with superior performance. This makes your Dominar, unbeatable and unchallenged on every street.

Before you ride out, please read this Owner's Manual carefully and familiarise yourself with the operation mechanism, controls and maintenance requirements of your Dominar 400. This will ensure you a safe and trouble free ownership experience.

To keep your bike in perfect running condition and deliver consistent performance, we have specially programmed the periodic maintenance services which includes 3 free services and subsequent paid services, as per the schedule contained in this booklet. We earnestly advise you to avail all these services at any of our Bajaj Dealers, who

are well equipped with all necessary facilities, genuine parts, oil and trained manpower to ensure the best care for your Dominar. Your '**Dominar 400**' comes with a warranty of **5 years or 75,000 Kms**, whichever occurs earlier from the date of sale. For details please refer to "Warranty: Scope & Limits" given in this manual.

Should you require any addition information, feel free to contact us on helpline numbers given on backside of cover page or e-mail us at: [customerservice@bajajauto.co.in](mailto:customerservice@bajajauto.co.in) or visit the Bajaj Auto website [www.bajajauto.com](http://www.bajajauto.com)

Also, do like our facebook page [www.facebook.com/BajajDominar](https://www.facebook.com/BajajDominar) and subscribe to our Youtube channel to stay tuned on any new information on the brand.

**GET SET TO DOMINATE THE NIGHT!**

# TABLE OF CONTENTS

SR.	DESCRIPTION	PG. NO.		
1.	Technical Specification	1	16.	Good Riding Habits 21
2.	Identification Data	3	17.	Safe Riding Tips & Monsoon Care 22
3.	Location of Parts	4	18.	Engine Oil 23
4.	Steering cum Ignition lock	5	19.	Tubeless Tyre & Tyre Pressure 24
5.	Fuel Tank Cap & Secondary Speedometer	6	20.	Battery 25
6.	Primary Speedometer Details	7	21.	Engine Cooling System / Coolant 26/27
7.	Twin Channel ABS System	9	22.	Periodic Maintenance Information 28
8.	Primary Speedometer Setting	10	23.	Brake Fluid / Headlamp Care 30
9.	Control Switch RH	12	24.	Usage of luggage straps with bungee cord 31
10.	Automatic Headlamp & Lights Operation	13	25.	Free Service Guidelines 32
11.	Control Switch LH	14	26.	Periodic Maintenance & Lubrication Chart 33
12.	Removal of Pillion & Rider Seat / Tool kit	15	27.	Non Use Maintenance 36
13.	Fitment of Rider & Pillion Seat	16	28.	Delivery Certificate 37
14.	Daily Safety Checks	17	29.	Warranty Scope & Limit 38
15.	How to ride your Bike	18	30.	Battery Warranty Card 41

## SAFETY AND WARNING INFORMATION:



Warning: This indicates that a potential hazard or injury to you or other persons & to the vehicle can happen if advice provided is not followed.



Caution: This indicates that a potential hazard that could result in vehicle damage. Follow the Advice provided with the caution.

## NOTICE

The description and illustration in this booklet are not to be taken as binding on the manufacturers. The essential features of the type described and illustrated herein remaining unaltered. Bajaj Auto Limited reserves the right to carry out at any moment without being obliged to bring this booklet upto-date & to do modifications on the vehicle, parts or accessories as may be convenient and necessary.



## TECHNICAL SPECIFICATIONS

Engine	: 4 Stroke, Single Cyl.
Bore x Stroke	: 89.0 mm x 60.0 mm
Engine Displacement	: 373.27 cc
Compression Ratio	: 12.1 : 1
Idling Speed	: 1700 $\pm$ 100 RPM
Max. Net Power	: 29.41 KW / 40 PS at 8650 RPM
Max. Net Torque	: 35 Nm at 7000 RPM
Ignition System	: 12 V, DC
FI system	: Multi point injection into manifold BOSCH
Spark Plug	: 3 Nos.
Spark Plug Gap	: 0.8 ~ 0.9 mm
Lubrication	: Wet sump forced
Transmission	: 6 speed constant mesh
Gear Shifting Pattern	: 1 Down 5 Up
Engine Cooling	: Water cooling
Starting Aid	: Electric starter

Fuel Tank Capacity	
Full	: 13 liters
Usable Reserve	: 3 liters
Unusable Reserve	: 600 ml
Fuel Grade	: Super Unleaded RON-91 (Research Octane Number)
Dimensions	:
Length	: 2156 mm
Width	: 836 mm
Height	: 1112 mm
Wheelbase	: 1453 mm
Ground clearance	: 157 mm
Tyre Size	
Front	: 110/70-R17, Tubeless
Rear	: 150/60-R17, Tubeless
Tyre Pressure	
Front	: 2.04 Kg/cm <sup>2</sup> (29 PSI)
Rear (Solo)	: 2.25 Kg/cm <sup>2</sup> (32 PSI)
Rear (with pillion)	: 2.25 Kg/cm <sup>2</sup> (32 PSI)
Front & Rear Brake	: ABS Disc Brake



Electrical System	: 12 Volts DC
Head Lamp	: LED
Position Lamp	: LED
Tail /Stop Lamp	: LED
Side Indicator lamp	: LED (4nos. Amber)
Neutral Indicator	: LED, Green
Hi Beam Indicator	: LED, Blue
Turn Signal Indicator	: LED, Green
Speedometer-back light	: LCD, White
Fuel Level Indicator	: LCD Bar
Low Oil Pr. Indicator	: Alarm Message
Malfunction Indicator	: LED-Yellow
Coolant Temp. Indicator	: Alarm Message
Low Battery Indicator	: Alarm Message
Bajaj Logo	: Display in Dot Matrix
RPM Limit	: LED-Amber
Service Reminder	: Alarm Message
Generic Alarm Indication	: Amber

Side Stand Indicator	: Alarm Message
ABS Indicator	: LED-Yellow
Rear No. Plate Lamp	: LED
Horn	: 12V DC
Battery	: 12V 8Ah VRLA
Vehicle Kerb Weight	: 184.5 kg.
Gross Vehicle Weight	: 334.5 Kg.


#### NOTES

- All dimensions are under UNLADEN condition.
- Above information is subject to change without any notice.
- This vehicle complies to BS IV standards.
- AHO is government regulation.

## IDENTIFICATION DATA

The Frame and Engine serial numbers are used to register the motorcycle.

They are the unique alpha-numeric codes to identify your particular vehicle from others of the same model and type.



### ENGINE NUMBER LOCATION


On LH Side Crankcase Near Gear  
Change Lever (Alpha-Numeric - 11 Digits)

### FRAME NUMBER LOCATION

On Seat Mounting Bracket  
(Alpha-Numeric - 17 Digits)



# LOCATION OF PARTS



## STEERING CUM IGNITION LOCK



### STEERING CUM IGNITION LOCK

It has three positions.

●	LOCK: Steering locked. Ignition OFF.
⊘	OFF: Steering unlock. Ignition OFF.
⊙	ON: Steering unlock. Ignition ON.

### TO LOCK THE STEERING

To lock the steering, turn the handle bar to the left side. Turn the handle bar to the left or right. Push & Rotate the key to "LOCK" position & remove the key.

**Steering locking on handle position left hand side only.**

### TO UNLOCK THE STEERING

Insert the key in steering cum ignition lock. Push & Rotate it clockwise to "OFF" or "ON" position.

### KEY

A common key is used for 'Steering cum Ignition lock', 'Fuel tank cap' & 'Rear Seat'

# FUEL TANK CAP & SECONDARY SPEEDOMETER

Speedometer display will work when Ignition switch is in 'ON' position.




## FUEL TANK CAP

- To open the fuel tank cap, open the flap. Insert the key in the lock and turn it clockwise and lift fuel tank cap.
- To lock the 'Fuel Tank Cap' insert the key in the lock and turn it clockwise and press fuel tank cap. 'Click' sound ensures cap is fully locked.

## PRECAUTION


Don't attach metallic 'Key chain' as it may damage paint of petrol tank cover.



1. Odometer : The Odometer shows the total distance that the vehicle has covered. Odometer can not be reset to 'Zero'. Range 0 to 9,99,999 km.
2. Trip Meter : Trip 1 & Trip 2 shows the distance traveled since it was last reset to zero. Rolls over to zero after 999.9 km & continue updating.
3. Mode Button: Mode button used for changing the mode while selecting & setting Trip1, Trip2, ODO, INFO, Clock & Service reminder.
4. Set Button: Set button used for setting Clock & Service reminder. On pressing set button display in primary speedometer scrolls.
5. Digital Clock: It indicates time in HR: MM (AM/PM)
6. Gear indication: It will display gear position from 1 to 6. It will display 0 when vehicle is in neutral position.

## PRIMARY SPEEDOMETER DETAILS

SPEEDOMETER DISPLAY WILL WORK WHEN IGNITION SWITCH IS IN 'ON' POSITION.



1. Tachometer Dial: It shows engine speed in RPM.
2. ABS Indicator (Yellow) (Ⓢ): With Ignition switch ON the ABS indicator glows. When vehicle speed is more than 5 Km/hr, the ABS indicator goes OFF, if this indicator glows while vehicle is running, it means there is problem in ABS unit.
3. Hi Beam Indicator: When Headlight is 'ON' & Hi beam or 'PASS' is selected then Hi beam indicator will glow.
4. Neutral Indicator: When the transmission is in Neutral, Neutral indicator will glow - 'N' in primary speedometer & O will be displayed in secondary speedometer.
5. Malfunction Indicator (⚠): It glows whenever any abnormality is noticed in functioning of FI system components.

6. Turn Signal Indicator (LH & RH) : When Turn signal switch is pushed to Left or Right, Turn Signal Indicator - LH or RH will flash.
7. Generic Alarm Indicator (⚠): It remains continuously ON if alarm message = 1, it blinks if alarm messages are more than 1.
8. Engine RPM Limit Indicator: It reminds rider to drive in safe engine RPM.

Within initial 2000 kms running (RUNNING IN period)

- RPM limit indicator blinks @ 6700 to 7000 RPM
- RPM limit indicator continuously glows if RPM is  $\geq 7000$  km.

Beyond 2000 kms running -

- RPM limit indicator blinks @ 9200 to 9500 RPM
- RPM limit indicator continuously glows if RPM is  $\geq 9500$  km

9. Bajaj Logo: Bajaj logo flying 'B' glows with ignition 'ON'
10. Fuel Level Indicator: It shows approximate fuel level in fuel tank.
11. Low Fuel Level Indicator :  
Fuel bar = 1 - Bar 1 glows steady & low fuel symbol blinks  
Fuel bar =  $< 1$  - Bar 1 & low fuel symbol both

blinks

Fuel bar = 2 - Low fuel symbol glows steady

12. Speedometer: Vehicle speed will be displayed in digital form in km/h.

13. Alarm / information messages will be displayed on Primary speedometer in Dot Matrix format.

## Messages display area for (A & B)



## Information Messages (B)

Information message will be displayed according to selection of ODO / Trip 1 / Trip 2 / Info in secondary speedometer.

ODO	Trip 1	Trip 2	InFO
Dynamic FC	Average fuel Consumption 1	Average fuel Consumption 2	Active warning 1
Service	Av Sp 1	Av Sp 2	Active warning 2
	Trip Time 1	Trip Time 2	Active warning 3
	Fuel range	Fuel range	-----

## Alarm Messages (A)

Priority	Alarm message	Related component
1	ECU CAN Communication Failure	ECU CAN failure
2	ABS CAN Communication Failure	ABS CAN failure
3	S CAN Communication Failure	Secondary speedo CAN failure
4	Engine kill ON	Engine Kill switch
5	Side Stand Down.	Side stand
6	Low Oil pressure	Oil pressure
7	High Coolant Temperature	Coolant temperature
8	Low Battery (Battery voltage 11.5VDC for more than 60 sec)	Battery Charge
9	Low Fuel Level.(Fuel bars =2)	Fuel level
	REFUEL (Fuel bars=1)	
10	Fuel level sensor failure(open or short circuit in fuel level sensor)	Fuel level sensor failure
11	Coolant sensor failure	Coolant temperature sensor failure
12	Service Reminder with service icon	Service Reminder

**NOTE**

After switching 'ON' the ignition switch, the following indications will remain 'ON' till engine is started.

ABS Indicator | Malfunction Indicator



## TWIN CHANNEL ABS SYSTEM



Always maintain a safe distance between you and objects ahead. Vehicle speeds should always be reduced during extreme road conditions. The braking distance for motorcycle equipped with an anti-lock braking system may be longer than for those without it on rough road conditions. During these conditions the vehicle should be driven at reduced speeds.

When you apply Front brake / Rear brake under conditions which may lock the wheels, you feel a corresponding sensation (pulsation) in Front brake lever / Rear brake pedal. This is normal and it means your ABS is active.

**Also it is recommended to use both front & rear brakes simultaneously.**

Always slow down when cornering. The anti-lock brake system cannot prevent accidents resulting from excessive speeds.

If the ABS warning light is ON and stays ON, you may have a problem with the ABS. In this case, however, your regular brakes will work normally.

### INSTRUCTIONS

Incase, Malfunction indicator & ABS indicator glows and alarm message of high coolant temperature, low battery & low engine oil pressure is displayed in speedometer, bring the vehicle to nearest BAL dealership for inspection / repair.

## SECONDARY SPEEDOMETER SETTING



### TRIP METER RESET

- Mode & Set push button is provided for selecting & resetting 'ODO/TRIP1/TRIP2'.

1.	Press mode push button for less than 2 sec.	Mode changes from 'ODO/TRIP1/TRIP2'
2.	Press set push button for more than 5 sec.	Selected 'TRIP1/TRIP2' will reset. Other TRIP mode will continue updating.

### SERVICE REMINDER RESET (🔧)

'Wrench' symbol glows when ODO meter reading reached to set Kms.

This icon will glow at-

1st : 450 Kms                      2nd : 4450 Kms  
3rd : 9450 Kms                    4th : 14450 Kms

& subsequently at each 5000 Kms.

#### NOTE

Bring the motorcycle at authorised BAL dealership for re-setting the service reminder icon.






## CLOCK RESET

- Digital clock indicates time in HR & MM separated by colon ':'
- It is 12 hour clock.
- Initially icon ':' will be blinking
- Clock setting is possible in TRIP 1 mode only.

1.	Press mode push button for less than 2 sec.	TRIP1 Mode selected
2.	Press mode & set push button together for more than 2 sec.	Icon ':' stops blinking Digits starts blinking
3.	Press mode button for less than 1 sec.	Hour digits will increase.
4.	Press set button for less than 1 sec.	Minutes digits will increase.
5.	Press mode & set button together for more than 2 sec.	Set value will be saved Exit clock setting mode Digits stop blinking icon ':' start blinking
6.	Clock set mode is selected & no editing is carried out for more than 5 sec.	Auto exit without saving set value. If engine / vehicle rpm is given then system will exit from clock set mode without saving set value.

## CONTROL SWITCH RH



### A. HEAD LIGHT SWITCH

It has 2 positions.

☰	Pilot Mode
☀	Headlight Mode

### B. STARTER BUTTON

Starter button operates the electric starter. It is recommended to start the engine with the transmission in neutral.

Vehicle in Gear - Press clutch lever & operate starter button to start the engine.

### C. ENGINE KILL SWITCH













The engine kill switch is used for switching ON & OFF the engine.

⊗	Engine OFF
⊙	Engine ON


# AUTOMATIC HEADLAMP & LIGHTS OPERATION

## NOTE

- Your vehicle has a safety feature which turns ON the headlamp automatically, once the engine is started. This provides better visibility to other road users.
- While riding, low beam or hi beam mode can be switched ON by operating the low/hi beam selector switch, keeping the light switch in head light mode.

IGNITION SWITCH	ENGINE	LIGHT SWITCH		LOW/HI BEAM SELECTOR SWITCH		THE FOLLOWING LIGHTS WILL GLOW	EFFECT IF PASS SWITCH IS PRESSED
							
ON ( ? )	OFF	Any Position ↔ 		Any Mode ↑ OR ↓ 		Front Position lamp, Tail Lamp, Rear Number Plate Lamp, Control Switch Illumination, Both speedometer illumination	<b>Headlamp Hi beam &amp; Low beam will glow.</b>
	Started		Toward right (Pilot mode)	Any Mode ↑ OR ↓ 		Front Position lamp, Tail Lamp, Rear Number Plate Lamp, Control Switch Illumination, Both speedometer illumination, Headlamp Hi beam	<b>Headlamp Low beam will also glow.</b>
			Toward Left (Headlight mode)		Low beam mode (  )	Front Position lamp, Tail Lamp, Rear Number Plate Lamp, Control Switch Illumination, Both speedometer illumination, Headlamp low beam	<b>Headlamp Hi beam will also glow.</b>
						Hi beam mode (  )	Front Position lamp, Tail Lamp, Rear Number Plate Lamp, Control Switch Illumination, Both speedometer illumination, <b>Headlamp Hi beam &amp; low beam</b>

## CONTROL SWITCH LH



### LEFT HANDLE BAR SWITCHES

#### D. HIGH / LOW BEAM SWITCH

When headlight is ON, High or Low beam can be selected with this switch. Hi beam indicator light located on Speedo console will glow when high beam is selected.

☰ : High Beam    ☷ : Low beam

#### E. TURN SIGNAL SWITCH

When the turn signal knob is pushed to Left (↵) or Right (↶) respective indicator will start blinking. To stop blinking push the knob in & release.

#### F. HORN BUTTON

(🔊) Press button for sounding horn.

#### G.PASS SWITCH


Press the switch to put on Hi Beam of head light. It is used to give signal to vehicles coming from opposite side while overtaking.

# REMOVAL OF PILLION & RIDER SEAT / TOOL KIT



## REMOVAL OF PILLION SEAT

- Insert Key into lock (A)
- Turn the key clock wise.
- Lift rear end of 'Rear seat'
- Pull 'Pillion seat' backward side.
- Take out 'Pillion seat'.



## REMOVAL OF RIDER SEAT

- First remove 'Pillion seat'.
- Remove 'Rider seat' mounting bolts (B).
- Pull backward rear end of 'Rider seat'.
- Take out 'Rider seat'.

## TOOL KIT LOCATION

- Tool kit fitment location is provided below pillion seat assembly.
- Tool kit to be clamped on Pillion seat assembly by rubber strap.


## FIRST AID KIT LOCATION

- It is located on LH side of Seat Cowl below the 'Pillion seat'.




First Aid Kit & Tool Kit

# FITMENT OF RIDER & PILLION SEAT



## FITMENT OF 'RIDER SEAT'

- Match the bracket of 'Rider seat' (A) with slot (B), Ensure availability of rubber damper of seat center.
- Slide 'Rider seat' toward petrol tank.
- Match 'Rider seat' rear brackets (C) with the holes (D) provided on chassis & Tighten the bolts (E).



## FITMENT OF 'PILLION SEAT'

- First make sure 'Rider seat' is fitted properly.
- Insure 'Tool kit' is located properly on pillion seat
- Place 'Pillion seat' on fitment location.
- Match the bracket of 'Pillion seat' (F) with Hook (G).
- Slide pillion seat towards rider seat.
- Insert lock rod (H) of seat into seat lock (I).
- Press rear portion of seat from top.



## DAILY SAFETY CHECKS

Before riding motorcycle be sure to check following items. Please give proper importance to these checks and perform all of them before riding motorcycle.

If any irregularities are found during these checks, refer to the Maintenance chapter & see your dealer for the action required to return the motorcycle to a safe operating condition.




Warning: Failure to perform these checks every day before you ride may result in serious damage or severe accident.

- Enough fuel level for planned distance of journey. No fuel leakage in fuel lines.
- Engine oil level (between upper and lower level mark) at vehicle upright position on level surface.

- Throttle cable play of 3 mm. Smooth operation and positive return to closed position.
- Brake Fluid level above MIN mark provided on reservoir. (Both front and rear)
- Drive Chain slack of 20 ~ 30 mm adequately lubricated by OKS spray. This is available with BAL dealer for sale.
- Function of all lights & horn
- Clutch lever play - 3 mm
- Check Coolant level between MIN and MAX mark in coolant reservoir tank at vehicle upright position on level surface.
- Smooth steering movement without restriction.
- Side stand return to It's fully up position.
- Correct inflation pressure in both tyres  
Adequate tyre tread depth - no cracks / cuts.
- Correct rear viewing span adjustment of mirror.

# HOW TO RIDE YOUR BIKE



## 1. STARTING THE ENGINE

- Turn ignition switch key to ' ? ' position.
- Put kill switch in ' Q ' position.
- Confirm that transmission is in neutral / press the clutch lever if transmission is in gear.
- Keep throttle closed & press starter button,
- Release starter button as soon as engine starts.



Caution: Do not operate the starter continuously for more than 5 seconds otherwise battery would get discharged.

Wait 15 sec. between each operation of the starter which will facilitate battery to recover.

NOTE

The motorcycle is equipped with a Clutch switch. This switch ensures that engine does not start if the transmission is in gear. However, the engine can be started in any gear if the clutch lever is pressed.

NOTE

In case of battery discharged condition, vehicle will start by push start.

## 2. SHIFTING GEARS

- Close throttle & depress the clutch lever.
- Shift into next higher or lower gear.
- Open the throttle and release the clutch lever slowly and simultaneously.

## 3. MOVING OFF

- Check that side stand is up.
- Depress the clutch lever.
- Shift into 1<sup>st</sup> gear.
- Open the throttle and release the clutch lever slowly and simultaneously.
- As the clutch starts to engage, open the throttle a little more, giving the engine just enough rpm to keep it from stalling.

## RECOMMENDED SPEED FOR SHIFTING DOWN

From 6 <sup>th</sup> to 5 <sup>th</sup> Gear	71 km/h
From 5 <sup>th</sup> to 4 <sup>th</sup> Gear	59 km/h
From 4 <sup>th</sup> to 3 <sup>rd</sup> Gear	48 km/h
From 3 <sup>rd</sup> to 2 <sup>nd</sup> Gear	37 km/h
From 2 <sup>nd</sup> to 1 <sup>st</sup> Gear	22 km/h

## 4. BRAKING

- Close the throttle completely, leaving the clutch engaged (except where shifting gears) so that the engine braking will help slow down the motorcycle.
- Shift down one gear at a time so that you are in Neutral when you come to a complete stop.
- When stopping, always apply both brakes at the same time.



Warning : When shifting down to lower gear, do not shift at such high speed that engine rpm jumps excessively. This may cause engine damage, & rear wheel may skid. Downshifting should be done at recommended speeds as shown in table above.

## 5. STOPPING THE VEHICLE

- Close the throttle completely.
- Shift the transmission into neutral.
- Bring the vehicle to complete stop.
- Turn the ignition switch off.

## 6. RUNNING IN

- Proper running-in is important for the better life & trouble free performance of the vehicle.
- During first 2000 kms running-in period do not exceed following speed limits.

Kms	1st	2nd	3rd	4th	5th	6th
0 - 1000	10	20	30	40	50	60
1000 - 2000	20	30	40	50	60	70

- Always keep the speed below the limits mentioned in the table.
- Do not race the engine excessively.
- Do not start moving or race the engine immediately after starting. Run the engine for a minute at idle speed to give the oil a chance to workup into the engine.

## 7. VEHICLE PARKING

- This vehicle do not have main stand.
- Support the motorcycle on a firm level surface with the side stand.
- Lock the steering on LHS.



### CAUTION

1. Do not park on a soft or steeply inclined surface as the motorcycle may fall over.
2. Always ensure side stand is UP while starting off.  
**Ignition will be cut off if vehicle is attempted to be driven in side stand DOWN condition** and

'side stand down' message will be displayed in primary speedometer.

3. If engine coolant temperature crosses 110°C, 'Coolant Temperature high' alarm message will be displayed on primary speedometer indicating engine is overheated.

**If vehicle is further driven in such a condition coolant temperature will increases up to 115°C & ECU will not allow engine to run above 4500 rpm.**

4. Always maintain Min 3.00 Liters fuel in fuel tank for smooth functioning of fuel pump.
5. Always insist for use of 91 Octane number fuel for smooth functioning of bike.
6. This vehicle has new 'A & S clutch'(Assist & sleeper).

Due to this, very little force is required for clutch lever operation. you won't feel jerks while sudden down shifting.

Slight pulsation is felt at clutch lever. This is normal & indicates 'A & S clutch' is working well.

7. Power output of headlight is only 20W max & hence continuously glowing headlight will not damage / reduce life of battery.

## GOOD RIDING HABITS

- Always fill 91 octane petrol at reputed petrol pumps for optimum performance of bike.
- Always maintain minimum 3 liters petrol in petrol tank for smooth functioning of fuel pump.
- Always maintain recommended air pressure in both the tyres.
- Always maintain engine oil / coolant level between MIN & MAX mark at vehicle upright position on level surface.
- Ride smoothly and steadily at an optimum driving speed of 40 to 50 Km/h
- Avoid harsh braking.
- Always apply both brakes simultaneously.
- Always ensure brake fluid level in both front & rear reservoir is above MIN mark.
- Change the gear judiciously according to the speed and load requirement.
- Don't overload the vehicle above the specified payload.
- Use the accelerator judiciously.



- Cut off the engine if you want to stop for more than two minutes.
- Press clutch lever fully while shifting gears.
- Always ensure battery is fully charged.

## HOW TO CHECK MILEAGE (FUEL EFFICIENCY)

Best way to calculate mileage is by following the full tank to full tank method.

- Fill way tank full up to small mouth (brim).
- Run the bike for say 100 km.
- Fill the tank full again in same fuel filling station, probably with same fuel dispenser.
- Divide kilometer run / fuel quantity filled.

## SAFE RIDING TIPS & MONSOON CARE

### Safe Riding Tips


- Always wear Helmet while driving or riding. Your helmet should conform to appropriate Indian standards.
- Read thoroughly the instructions given in this manual and follow them carefully.
- Avoid unnecessary accessories for the safety of both rider and other motorists.
- Get familiar and follow traffic rules & regulations in your states as well as general traffic signs.
- Familiarise yourself well with starting, acceleration and braking of the vehicle.
- When applying the brakes, use both front & rear brakes simultaneously.
- Riding at proper speed and avoiding unnecessary acceleration and braking are important not only for safety and low fuel consumption, but also for longer life of the vehicle.
- During monsoon drive the vehicle more cautiously. Remember vehicles skid more easily during light showers.
- Drive cautiously. Start early & reach your destination safely.

- Always carry vehicle registration & insurance papers, and a valid driving licence with you.
- Avoid driving on loose sand or stones where vehicle is likely to skid.
- Properly wrap-up loose clothes while driving or riding to avoid entangling in wheel or other objects on road.
- Always concentrate on riding for safety.

## MONSOON CARE

- It is suggested to customer to take appropriate care in area of heavy monsoon or high rainfall. The appropriate surface preventive coat to avoid rusting / poor surface finish on account of adverse atmospheric conditions.
- Vehicle cleaning to be done with soft & clean wet cloth to avoid scratches on painted parts.
- Clean & lubricate all the important parts as detailed in a periodic maintenance chart.
- Do not apply direct water jet on painted, electrical / electronic parts.
- Do not obstruct engine cooling by adding mud protection sheet from front.

## ENGINE OIL



A: Oil Filler Cap

B : Oil Level Gauge

### LEVEL CHECKING

- Check engine oil level every day at vehicle upright position on level surface (at engine cold condition).
- Check oil level through oil level gauge 'B'.
- Always maintain engine oil level between upper (C) and lower (D) mark provided on Cover RH. Top up with specified grade of oil if the oil level is below lower level mark.

### ENGINE OIL CAPACITY

- Refill at servicing: 1700 ml.
- During engine overhaul: 1950 ml.




#### CAUTION:

It is most important to adhere to recommended grade & frequency of oil change for the purpose of long life of critical engine components. For details refer periodic maintenance chart.

### RECOMMENDED ENGINE OIL:

Always insist on Bajaj Genuine Engine Oil for optimum engine performance & warranty benefits. It is a specially formulated oil for Dominar 400.

Model	Recommended Engine oil	Grade
Dominar 400	Bajaj DTS-I 10000 10W50	SAE 10W50 API 'SJ' or JASO 'MA2'



C : Engine oil level upper limit

D : Engine oil level lower limit

- **Engine oil replacement frequency: 1<sup>st</sup> service & then every 10,000 Km.**
- **Engine oil level top-up frequency: Every 5000 km.**

# TUBELESS TYRE & TYRE PRESSURE



## TUBELESS TYRE

The main advantage of tubeless tyres is in case of puncture the rate of air leak is very slow, hence customer can easily drive the vehicle upto nearest puncture repair shop for removing puncture.

### NOTE

Incase the motorcycle is fitted with imported tyres, compliance to respective Indian standard & central motor vehicle rules has been ensured.

## WHEEL PUNCTURE

- Visit nearest known tubeless tyre repair shop to remove puncture.
- Remove puncture by Filler or Plug method only.
- Do not use patch method to remove puncture of tubeless tyre.

## CAUTION

Tubeless tyres are fitted in this motorcycle. The walls of the tyres in contact with the wheel rim should not be damaged in any way during fitment / removal of tyre. The tyre side walls in contact with wheel rim seals air.

## TYRE PRESSURE

Keep appropriate tyre pressure as mentioned below to increase life of the tyre & for better fuel consumption.

Dominar 400	Front	29 PSI
	Rear (Solo)	32 PSI
	Rear (with Pillion)	32 PSI



## BATTERY



### 12V - 8 AH VRLA

- Battery is located below Rider seat.

### BATTERY FEATURES

- No topping-up is required
- Reduced self discharge, Enhance safety.
- No vent tube open to atmosphere hence no discharge of electrolyte through vent tube.

#### CAUTION

Do not drive / run vehicle in battery disconnected condition. It may lead to damage of electrical / electronic components.

- Environment care must be taken to dispose off the used battery.
- It is always recommended to hand over the same to the Authorised battery / Bajaj dealer for proper disposal of the same.
- When 'Low battery icon' pop-up in speedometer display, it is advised to reach Bajaj dealer & get it charged immediately.
- Warranty for battery is 18 months from the date of purchase of vehicle.

### HOW TO KEEP BATTERY HEALTHY?

- Switch 'Off' ignition when engine is not running.
- Get battery checked/ charged during periodic services.
- Do not press starter button for more than 5 sec. After 3 successive cranking, wait for 15-20 sec. for battery to recover.
- Do not add extra electrical accessories such as - Remote, Bigger Horn, Musical brake light etc. This will reduce life of battery & may damage ECU.
- Disconnect battery +ve & -ve wires if vehicle is to be stored for more than 2 weeks. This avoids self discharge.

# ENGINE COOLING SYSTEM




Coolant Expansion Tank

- Coolant is provided for cooling of engine.
- Water pump in the engine circulates the coolant in cooling system.
- The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap (A).
- Heat expansion causes excess coolant to flow into expansion tank.
- When the coolant temperature drops, this surplus coolant is sucked back into the cooling system.
- Cooling fan is provided for cooling of coolant circulated through radiator fins.

## NOTE

Fan will start at temp 95.3°C and stops at 90°C. This is normal condition & it indicates cooling system functioning well.



## WARNING:

During operation, the coolant gets very hot & is under pressure. In case of scalding, rinse immediately with lukewarm water. Do not remove radiator cap, radiator hose or other cooling system components when the engine is hot. Allow the engine & cooling system to cool down.

## COOLANT

### ⚠ WARNING:

Coolant is poisonous and causes health hazard.


Avoid contact between coolant & skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor.

Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come in contact with coolant. Keep coolant out of the reach of children.

## COOLANT SPECIFICATIONS

Use antifreeze ready to use  
"Bajaj Koolex" coolant only.

Total coolant quantity : 1000 ml.  
(750~780 ml in radiator &  
220~230 ml expansion tank).




Expansion  
Tank Cap (A)

Coolant Level  
Inspection  
Window

## COOLANT TOP UP

- Park vehicle at upright position on level surface. Remove 2 nos screws to access expansion tank cap.
- Check coolant level in engine cold condition only.
- Ensure coolant level is between Min & Max mark.
- Always top up coolant through expansion tank cap (A).
- Always replace coolant with "Bajaj Koolex" coolant only.
- Use nitrile rubber hand gloves while draining & topping up coolant.
- Do not top up coolant through radiator cap.

## PERIODIC MAINTENANCE INFORMATION



### SPARK PLUG

- Remove spark plugs by using plug spanner.
- Clean the spark plugs at 20000 Kms.
- Adjust the gaps if incorrect by bending outer electrode carefully.

**Spark Plug Gap:** 0.8 to 0.9 mm.

#### Spark Plug

- (2 Nos.)** : CHAMPION (PRG6HCC)  
(LH 'A' + RH 'B')
- (1 No.)** : CHAMPION (RER6YCA)  
(Center 'C')

### DRIVE CHAIN SLACKNESS

- Chain slackness will have to be adjusted whenever required.
- Std. Chain slackness 20 ~ 30 mm.
- Marking on chain adjusters should be identically positioned on both sides.



Ensure application of 10 Kg.m (98.1 N.m) torque to rear axle nut.



## METHOD OF O-RING CHAIN LUBRICATION

- Put vehicle on side stand & tilt the vehicle to make rear wheel free. Clean the chain by using lint free cloth (If excessive mud / slush found approach Bajaj dealer for proper cleaning).
- Shake the can vigorously by holding vertically upright till the noise of steel ball inside heard uniformly.
- Hold spray can at the back of rear sprocket with extension tube nose at 5~10 cm.
- Rotate the wheel in reverse direction & spray the lube on middle portion of the chain up to full length of the chain.

## DRIVE CHAIN CLEANING

Drive Chain (O-ring type)

Drive chain must be cleaned & lubricated as per periodic maintenance schedule.

- 'O' rings must always be kept wet for best performance hence lubricate every 500 Km.
- **O-ring chain lubrication can easily be done by owners using Bajaj 'Chain Lube Spray Can' available with Bajaj dealers for sale.**



## BRAKE FLUID/HEADLAMP CARE



Rear Brake  
Fluid Reservoir

Front Brake  
Fluid Reservoir

### FRONT & REAR BRAKE FLUID LEVEL

- Front brake fluid reservoir is located on RH side of Handle bar.
- Rear brake fluid reservoir is located behind RH pillion holder bracket.
- To check the brake fluid level, park the vehicle at upright position on level surface. with handle bar in straight ahead condition.
- Always ensure that brake fluid level is above 'MIN' mark given on inspection Window.
- In case of level drop, use only DOT-4 brake fluid (from sealed container) for top up & replacement.

### HEADLAMP CARE

Condensation inside headlamp is a natural phenomenon.

Condensation occurs when atmospheric air containing water vapor or humidity enters the headlamp through the vents due to temperature difference. A thin film of fog can form on the inside surface of the headlamp lens. The thin fog will clear and exit through the vents during normal operating condition.

Condensation & fogging of headlamp lens may happen during rain or after washing.

Moisture condensation inside the headlamp lens will disappear gradually by switching ON the headlamp in high beam and driving the vehicle at 30 to 40 Kmph speed for about 15 minutes.

Time for evaporation will vary depending on the humidity of the ambient air.

#### NOTE

If fog inside the headlamp does not evaporate bring the vehicle to Bajaj Authorised Dealer for inspection.

## USAGE OF 'LUGGAGE STRAPS' WITH BUNGEE CORD

### USAGE OF 'LUGGAGE STRAPS' WITH BUNGEE CORD

If provided, luggage straps below pillion seat, then these straps to be used for bungee cords for clamping luggage on vehicle.

#### Procedure to use luggage straps :

- Open Pillion seat & take out front and rear luggage straps.(refer photographs A )
- Re-fit pillion seat on its position (B).
- Now you can use luggage straps to hook 'Bungee cord' (not supplied with vehicle) for clamping luggage on vehicle ©. (Maximum allowed luggage load is 15 Kg)

#### Caution :

Luggage straps can be used only for strapping a luggage bag or similar as shown in the pictures (C & D). The total weight of the bag and its contents shall not exceed 15Kgs.

While using the strap the user shall ensure that necessary precautions are taken in order to ensure that the:



- Luggage / luggage bag is well balanced on the seat and securely tied with help of suitable cord / rope which are strong enough for the purpose.
- Parts of the Vehicle are not damaged due to in appropriate luggage or due to the additional hardware used for securing same.

It is not recommended to use these straps to carry any articles which may damage the vehicle parts or affect the stability of the bike while driving

**Warranty is not applicable for any damages arising due to luggage over weight, sharp edges.**

When luggage straps are not in use follow below steps.

1. Front straps to be folded with velcro on strap ends & Insert the folded straps under rider seat
2. Rear straps to be folded neatly to approach the hooks & insert straps in hooks.



# FREE SERVICE GUIDELINES

VEHICLE IS TO BE SERVICED / REPAIRED AT BAL DEALERSHIP ONLY

## INSTRUCTION TO AVAIL FREE SERVICE THROUGH DIGITIZED FREE SERVICE COUPON

Please follow following procedure:

- Please provide your mobile number to Dealer at the time of buying of new Bajaj Vehicle.
  - In case of change in mobile number, please update to Dealer / ASD.
  - You will receive the Customer ID through SMS at the time of buying of new vehicle.
  - Please note the Customer ID in Owner's Manual for your reference.
  - During Free Service, please provide your Customer ID to Dealer / ASD workshop.
  - When you are at Dealership / ASD workshop for Free Service, you will receive the 'Unique Coupon Number' (UCN) through SMS in your mobile.
  - Please inform the UCN to Dealer / ASD at the time of Free Service.
- (ASD-Authorised Service Dealer)

CUSTOMER ID:

Periodic Service Criteria			
Service	Days	Kms	whichever occurs earlier
1st Free Service	30~45	500~750	
2nd Free Service	240	4500~5000	
3rd Free Service	360	9500~10000	
Subsequent Paid services	120 Days from last Service	Every 5000 Km after previous service	



## PERIODIC MAINTENANCE & LUBRICATION CHART

SR. NO.	OPERATION		RECOMMENDED FREQUENCY							REMARKS
		Service	1 <sup>st</sup> Free	2 <sup>nd</sup> Free	3 <sup>rd</sup> Free	Every 5000 Km after Previous Service				
		Kms	500 ~ 750	4500 ~ 5000	9500 ~ 10000					
1.	Clean the vehicle with water wash & dry completely	✓	✓	✓	✓	✓	✓	✓	✓	Ensure to prevent water entry in petrol tank, silencer & electrical parts. Use caustic free detergent for washing. During water wash ensure to cover the silencer tail pipe
2.	*Engine oil (Bajaj DTSi 10000 oil)	C,R	<input type="checkbox"/> R	Top-up	<input type="checkbox"/> R	Top-up	<input type="checkbox"/> R	Top-up	<input type="checkbox"/> R	BGO DTSi 10W50 synthetic
3.	Engine oil filter		<input type="checkbox"/> R		<input type="checkbox"/> R		<input type="checkbox"/> R		<input type="checkbox"/> R	
4.	Oil strainer & Evacuation Strainer	CL	CL		CL		CL		CL	Oil strainer cleaning at the time of oil change.
5.	Spark plug	CL, C,A					CL, C,A			C&A at 20,000 Kms. Replace after 40,000 Kms
6.	Air cleaner element	R					R			Replace after every 20,000 kms. Cleaning not required.
7.	In line fuel filter	R					R			Replace after every 20,000 Kms.
8.	Fuel pipe	C,R					C,R			Replace if required.
9.	Valve tappet clearance	C, A					C, A			Check & adjust at every 20,000 kms.
10.	Sealed drive chain cleaning & lubrication	C,L,A	C,L,A	C,L,A	C,L,A	C,L,A	C,L,A	C,L,A	C,L,A	Customer to apply OKS chain lub spray at 500 Kms.

✓ Tick in the box ☐ R after replacing the periodic parts.

# PERIODIC MAINTENANCE & LUBRICATION CHART

SR. NO.	OPERATION		RECOMMENDED FREQUENCY							REMARKS
		Service	1 <sup>st</sup> Free	2 <sup>nd</sup> Free	3 <sup>rd</sup> Free	Every 5000 Km after Previous Service				
		Kms	500 ~ 750	4500 ~ 5000	9500 ~ 10000					
11.	Air filter drain tube	CL			CL		CL		CL	Clean at every 10000 kms.
12.	Silencer drain hole cleaning	CL		CL	CL	CL	CL	CL	CL	
13.	End chamber tail pipe cleaning	CL		CL	CL	CL	CL	CL	CL	End chamber to be cleaned using brush.
14.	Brake pedal pivot pin	C,L,R	C	C,L,R	C,L,R	C,L,R	C,L,R	C,L,R	C,L,R	Use recommended AP grease.
15.	Brake pad - Check wear indicator	C,R	C,R	C,R	C,R	<div>R</div>	C,R	C,R	<div>R</div>	Replace brake shoes / pad at every 15000 Kms.
16.	Brake fluid level - top up / replace	C,A,R				C,A			<div>R</div>	Use recommended brake fluid (DOT4)
17.	Disc brake assly - Check functionality, leakage or any other damage.	C	C	C	C	C	C	C	C	
18.	All cables free play	C, A	C, A	C, A	C, A	C, A	C, A	C, A	C, A	
19.	Wiring harness & Battery connections-routing, tie bands & clamps tightness.	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	C,A,T	
20.	Battery charge condition	C, A	C, A	C, A	C, A	C, A	C, A	C, A	C, A	Use recommended Midtronics Battery Tester & VRLA battery charger
21.	Steering play	C, A	C, A	C, A	C, A	C, A	C, A	C, A	C, A	
22.	Ignition switch barrel cleaning & handle bar control switches contacts cleaning.	C,CL	C,CL	C,CL	C,CL	C,CL	C,CL	C,CL	C,CL	Use recommended WD40 spray

✓ Tick in the box ☐ R after replacing the periodic parts.

## PERIODIC MAINTENANCE & LUBRICATION CHART

SR. NO.	OPERATION		RECOMMENDED FREQUENCY							REMARKS
		Service	1 <sup>st</sup> Free	2 <sup>nd</sup> Free	3 <sup>rd</sup> Free	Every 5000 Km after Previous Service				
		Kms	500 750	4500 5000	9500 10000					
23.	Steering stem bearing & Cap steering bearing (Plastic)	C,CL L,R			C,CL L,R		C,CL L,R		C,CL L,R	Check & replace if damaged. HP Limaplex HTX3 grease for lubrication
24.	Side stand pin (Pivot Bolt Area)	CL,L			CL,L		CL,L		CL,L	Use recommended AP grease.
25.	All fasteners tightness	CT	CT	CT	CT	CT	CT	CT	CT	
26.	General lubrication-Clutch lever	L	L	L	L	L	L	L	L	Use recommended AP grease.
27.	Coolant level in expansion tank	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	Use recommended 'Ready to use coolant'.
28.	Coolant hose damage/clamps/leakage	C		C	C	C	C	C	C	
29.	Radiator fins	C		C	C	C	C	C	C	
30.	EVAP Drain tube cleaning	CL	CL	CL	CL	CL	CL	CL	CL	
31.	Front fork inner pipe & dust cap cleaning	C,CL	C,CL	C,CL	C,CL	C,CL	C,CL	C,CL	C,CL	Dust & mud accumulation on exposed fork inner tube to be avoided through regular cleaning for better fork seal life.

\*It is strongly recommended to use only Bajaj genuine oil.

C: Check, A: Adjust, CL: Clean, R: Replace, T: Tighten, L: Lubricate

### FOLLOWING ITEMS ARE CHARGEABLE TO CUSTOMER.

Oil, Coolant, Filters, All types of greases, Cleaning agents, Cables, Wear & tear parts, Rubber O rings/oil seals/pipes, Gaskets etc.

✓ Tick in the box ☐ R after replacing the periodic parts.

## NON-USE MAINTENANCE

Non-use maintenance is necessary if a vehicle remains off road for a longer duration (more than 15 days\*\*). The correct and careful non-use maintenance carried out before storing the vehicle will prevent the vehicle from rusting and from such other non-operational damages like fire hazards.

- Clean the entire vehicle thoroughly.
- Empty the fuel from the fuel tank and (if fuel is left in for a longer time, the fuel will break and gummy substance could clog the Fuel pump & Throttle body.
- Remove spark plug & put several drops of Engine oil into the cylinder. Self start engine over slowly a few times to coat cylinder wall with oil & install back spark plug.
- Set the vehicle on a box or a stand so that both wheels are raised off the ground.
- Use antirust spray (Proto Quick LTP 902 - P. No. : 37254039) on all vehicle fasteners & plated parts to avoid rust formation.
- Cover entire vehicle neatly. Make sure that storage area is well ventilated & free from any

source of flames or spark.

- Fill 10% excess air pressure in both wheels.
- Do not apply oil on front / rear brake disc, to prevent rusting. If the brake disc rusts during storage, do not attempt to clean it with soap water. The rust will go off automatically during first few application of brake.

### \*\* FOR BATTERY

- a. Remove battery and keep it on wooden plank, in properly ventilated area.
- b. Before taking the vehicle for use.
  - Get the battery recharged from the Authorised Service Center / Battery Dealer.
  - Apply petroleum jelly on terminals. (applicable to certain models).

### PREPARATION FOR REGULAR USE AFTER STORAGE

- Follow daily safety checks.

# DELIVERY CERTIFICATE

FRAME NO.    -    -  :

ENGINE NO.    -    -  :

Sold on.: \_\_\_\_\_

Customer's Name Mr/Mrs/Miss: \_\_\_\_\_

Address: \_\_\_\_\_ Contact No.: \_\_\_\_\_

I have taken possession of motorcycle along with the following items.

- |                   |   |
|-------------------|---|
| 1. Owner's Manual | 5. Standard Accessories                       |
| 2. 2 nos of key   | 6. Battery      Make _____ Sr. No. _____      |
| 3. Set of tools   | 7. Tyre      Fr      Make _____ Sr. No. _____ |
| 4. First Aid Kit  | Rr      Make _____ Sr. No. _____              |

The Vehicle has been delivered to my satisfaction & I have understood all terms and conditions of warranty, service schedules & maintenance tips and shall abide by them.

Customer's Signature

(To be filled in by the dealer)

Imp: "Do not detach this page from Owner's Manual"

Dealer Code :

Dealer Name :

Address :

Contact No. :

## WARRANTY: SCOPE & LIMIT

Bajaj Auto Limited gives the following warranty in respect of the '**Dominar 400**' motorcycle manufactured by them.

Every possible care and precaution has been taken to ensure quality in respect of the material & workmanship in the vehicles manufactured by us. Bajaj Auto Limited will repair or replace at their Authorised Vehicle Dealer, free of charge, part or parts thereof as may be found, on examination, to have manufacturing defect within a period of 5 Years or 75,000 Kms., whichever occurs earlier from the date of sale subject to fulfillment of condition stipulated in part A, B & C given here under

**Warranty is applicable for only first owner of vehicle.**

### PART A

Warranty claims in respect of such items like shock absorbers, speedometers etc. though claimed through us, are subject to acceptance of the respective manufacturers. In all such cases the decision of the respective manufacturer will be final and binding.

Proprietary parts warranty -

1 Year warranty for tyres / tubes / spark plugs & 18 months warranty for battery from the date of purchase will be warranted by their respective manufacturer & should be claimed on them directly by the customer. Bajaj Auto Limited shall not be Liable to replace them though

their dealer will give full assistance in preferring such claims.

Bajaj Auto Limited undertake no liability in the matter of consequential loss or damage caused due to the failure of the parts. Delay, if any, at the repairing workshop in carrying out repair to vehicle shall not be a ground for extending the warranty period, nor shall it give any right to the customer for claiming any compensation for damages.

Bajaj Auto Limited reserves the right either to repair or replace the defective parts.

Where a defective part can be replaced by part/s of alternative brand/s, which are normally used by Bajaj Auto Limited in the course of manufacture, Bajaj Auto Limited reserves the right to carry out the replacement by a part or parts of any such alternative brand/s.

This warranty and any claim arising there from is subject to Pune jurisdiction only.

### PART B

No claim for exchange or repair can be considered unless the customer :

- a. Ensures that immediately upon detection of the defect, he approaches any nearest Authorised Bajaj Vehicle Dealers & Recommended Authorised Service Dealers with the concerned vehicle and enables him

to remove and despatch the part / parts attributing to the manufacturing defect to the Company.

- b.** Produces the Owner's Manual, in original, to enable that dealer to verify the details.

It must be expressly understood that claims forwarded directly to us by the owner / customers will not be entertained at all and such defective part/parts thus forwarded by them will lie at our factory at their own risk, and this warranty shall not be enforceable.


## TO AVAIL BENEFITS OF WARRANTY, FOLLOWING ARE MANDATORY

1. Availing of Initial 3 Free Services without lapse.
2. Availing paid services at every 5000 kms. or 120 days whichever occurs first without any lapse.
3. Availing of all above services at the Authorised Vehicle Dealers.
4. Usage of only recommended engine oil  
"Bajaj DTS-i 10000 10W50" at specified frequency for drain interval of 10,000 kms. & engine oil level top-up at 5000 kms.
5. Replacing mandatory periodic parts such as air filter, oil filter etc. as per periodic maintenance schedule.

## PART C

Further this warranty is NOT applicable to :

1. Normal maintenance operations like brake & clutch adjustments, cleaning of fuel system, engine tune-up or such other adjustments.
2. Parts subjected to normal wear & tear like Clutch Plates, Brake Shoes, Chain, Sprockets, Fork Oil Seal, Spark Plug, Control Cables, Brake Pads.
3. Replacement of electrical items like self-start's wear and tear items (if fitted), bulbs & rubber components like grommets, 'O' rings, bellows as well as filters, packings, gaskets, fasteners etc.
4. Painted parts. Only blistering or peeling off of paint film are covered under warranty. Any defect arising out of external damages or due to usage of protective covers /additional protective coatings adverse atmospheric condition etc. is not allow like under warranty.
5. All consumables like Engine oil, Fork oil, Brake Oil, Coolant & Grease etc. are chargeable to customer.
6. Any defect arising due to above consumables not changed as per scheduled or if used other than the recommended one.
7. Never drive your bike through flooded roads or a patch damage to the engine parts due to water entry is not cover under warranty.

- 
8. All chrome plated parts are prone to rust or corrosion in coastal area or in acidic environment or due to neglected cleaning etc. However chrome film peeling is covered under warranty in general atmospheric conditions. Blue/ Yellow colouration of silencer near exhaust port is permissible and hence not covered under warranty.
  9. Oxidation of unpainted/painted crankcase, cylinder block, cylinder head etc. in acidic environment or in a coastal area.
  10. Valve lapping (De-carbonizing) if required to be done at 30,000 km, which is normal servicing requirement.
  11. Parts of the vehicle that have been subjected to misuse, accident, negligent treatment OR which have been used in conjunction with parts & an equipment not manufactured or recommended for use by Bajaj Auto Limited, if in the sole judgement of Bajaj Auto Limited, such use prematurely affects the performance and reliability of the vehicle.
  12. Parts of the vehicle that have been altered and modified or replaced in unauthorized manner like use of wider tyres, loud silencers etc and which in the sole judgement of the Bajaj Auto Limited affects its performance and reliability.

**13. Vehicles which are not being serviced at**

**recommended dealers as per the service schedule described or which have not been operated or maintained in accordance with the instructions maintained in the Owner's Manual.**

14. Vehicles used for any competition or race and/or for attempting to set up any kind of record.
15. Any failure arising due to use of adulterated or bad quality fuel.  
Parts affected due to bad fuel quality are not covered Under warranty.
16. If additional electrical accessories such as - Remote, Bigger Horn, Musical brake light etc. Fitted on vehicle.
17. If the vehicle has been used for commercial purpose like Taxi or any other means of commercial transportation.

Bajaj Auto Limited reserves the right to make any changes in design or to add any improvements on the vehicle at any time without incurring any obligation to install the same on a vehicle previously supplied and sold. Also, the conditions of this warranty are subject to alteration without any notice.

This warranty is an entire written warranty given by Bajaj Auto Limited for '**Dominar 400**' motorcycle and no other dealer or its or his agent or employee is authorised to extend or enlarge this warranty.



**BATTERY WARRANTY CARD**

MAKE OF BATTERY : \_\_\_\_\_ MFG. CODE OF BATTERY: \_\_\_\_\_

BATTERY SR. NO.: \_\_\_\_\_ BATTERY CHARGING DATE: \_\_\_\_\_

TYPE OF BATTERY: \_\_\_\_\_ VEHICLE SALE DATE: \_\_\_\_\_

NAME OF OWNER AND ADDRESS: \_\_\_\_\_

TYPE OF VEHICLE: \_\_\_\_\_ REG. NO.: \_\_\_\_\_

FRAME NO.: \_\_\_\_\_ ENGINE NO.: \_\_\_\_\_

**SERVICE RECORD**

Sr. No.	Date	Age Mths.	Specific Gravity	Voltage	Remarks	Dealer's Stamp & Signature	* Code
1.							
2.							
3.							
4.							
5.							
6.							

**\*CODE FOR REMARKS:**

LL : Low electrolyte level.

AE : Electrical system needs attention.

IR : Insufficient running of vehicle.

CB : Cover broken.

BC : Broken Container.

PM : Poor maintenance.

BA : Battery abused.

**NOTE**

Customer should insist that "Service Record" must be filled by respective authorised battery dealer as proof of specified maintenance for easy settlement of claim, if any.

# TO BE FILLED IN BY BATTERY DEALERS / DISTRIBUTORS IN CASE OF CLAIM

Name of Dealer & Code: \_\_\_\_\_

Date of claim: \_\_\_\_\_ Battery Type : \_\_\_\_\_

Serial No.: \_\_\_\_\_ Date of Fitment: \_\_\_\_\_

## FAILURE MODE (PLEASE TICK AS APPLICABLE)

- Loose connection
- Internal Short
- Plate Shedding
- Intercell Connection
- Does not Hold Charge
- Wrong Assembly
- Wrong Application
- Terminal Corroded
- Overcharge / Undercharge
- Reverse Charge
- High Specific Gravity Electrolyte
- Electrolyte Contamination
- Electrolyte Level not Maintained
- Left Lying Idle

# Claim Accepted

## Claim Rejected

Details of Repair, if any \_\_\_\_\_

**NOTE**

Please contact nearest respective authorised battery dealer for details immediately after purchase of vehicle.

**4T**  
Premium  
Engine Oil

**BAJAJ**  
MOTORCYCLES

# LONGEST ENGINE OIL CHANGE INTERVAL OF 10,000\* KM

Synthetic Engine Oil Ultimate Performance



Reduced  
Friction



Clean Engine  
Parts




Smooth  
Clutch Control




\*TOP UP RECOMMENDED AT 5000 KM.



ALWAYS USE  
BAJAJ GENUINE PARTS  
& HIGH PERFORMANCE  
ENGINE OILS




We are committed to provide the best of sales & service experience, however should you require any additional assistance, please call our Call centre on the number given below.

 : 7219821111

**Call charges are as applicable**

**Call centre timings :- Monday to Saturday  
(09.30 - 18.30 IST)**

 Please download customer care app from '**Google play store**' and '**Apple store**' and book the vehicles for servicing and more on your phone.

E-mail : [customerservice@bajajauto.co.in](mailto:customerservice@bajajauto.co.in)

Web Site : [www.bajajauto.com](http://www.bajajauto.com)

**CIN : L65993PN2007PLC130076**